

Content:

Preamp and bezel,
undersaddle pickup,
Endpin cable,
mounting plates with adhesive tape,
screws

Before mounting please ensure the endpin connector has been fitted to the guitar (see attached instructions).

1. Slide the provided bezel along the guitar side to find the point where the curve of the bezel matches the curve of the guitar.
2. Mark the positions of the ends of the bezel and place masking tape across the side of the guitar.
3. Measure the total width of the guitar side and mark the center point.
4. Place the template sticker between the strips of tape with the center marks lined up .
5. Cut out hole in guitar body following the inside edge of the black line on the template.
6. Place the bezel so that it fits precisely and drill with 1mm drill diameter four outside holes for bezel fix.
7. Take the bezel out and increase the four holes up to 3.6mm diameter.
8. Remove the protection paper from adhesive tape of the mounting plates.
9. Fit mounting plates from inside of the guitar and press on.
10. Put the bezel in place and screw the bezel into the mounting plates.
11. Install a fresh 9V battery. Be sure battery polarity is correct!
12. Connect the pickup cable and endpin output cable to the preamp and push the preamp into the bezel hole until it clicks into position.

