

# Installation Instruction for SH 700 NFX NANOFLEX Pickup System for Oud/Ud

## Content:

Active Nanoflex Pickup,  
Preamp with 3V Battery  
Preamp Holder

1. Loosen the strings.
2. Feed the pickup into the string lope from high string end of the bridge.
3. Place the cable holder close to the pickup and fix the pickup cable into it. This will stop the pickup cable to be sensitive on touch.
4. Remove the protective foil of the adhesive tape on the preamp holder and place preamp holder onto the side of the instrument.
5. Slide the preamp into the preamp holder.
6. Plug pickup cable into one of the preamp inputs (there is no difference which one you use).
7. Connect the preamp with a regular cable to an amplifier.
8. Turn the volume controls on the preamp and on the amplifier on.
9. Tune one of the middle strings and check the sound output.
10. Rotating the pickup you will find the position where the sound is clear and natural.
11. Tune the rest of the strings and play.
12. To store the instrument into the case you can remove the preamp from the holder.

**Nanoflex pickup for oud**



**Nanoflex pickup for oud**



**Preamp and preamp holder**

