

Installation Instruction for Shadow SH 925 Arch Top Mandolin Bridge with Piezo Pickup

Content:

Piezo-Pickup with bridge,
3.5mm (1/8") socket with double sided adhesive,
12 foot plugcable 6.3 mm/3.5 mm (1/4" to 1/8"),
Cable holder

1. Loosen strings and remove original bridge.
2. Test fit the new bridge in place of the original with the output wire toward the rear.
3. In necessary, shape the feet of the bridge to fit the top of the instrument or adjust string height.
4. Reinstall the bridge, adjust string height and retune instrument.
5. Mount the output socket holder in a convenient location on the instrument with the applied double sided adhesive.
6. Connect to an appropriate amplifier with standard instrument cable.

Note:

Piezo pickups and transducers have a very high output impedance. In order to get the optimum sound output we recommend an amplifier with low impedance input.